



Student Name:

Assignment:

Notes:

Project Name: Treasure Mover

Project Type: Blocks

Date: Mon Mar 02 2026

```
when started
  Turn on the Optical light to allow it to see the block color better
  set Optical2 light on
  repeat 5
    Move to the block
    drive forward for 305 mm
    turn left for 90 degrees
    drive forward for 150 mm
    wait 1 seconds
    Detects if the block color is red
    if Optical2 detects red ? then
      If the block is red the claw will close
      spin ClawMotor forward for 30 degrees
      drive reverse for 150 mm
      turn right for 180 degrees
      Drive to the other side of the Field
      drive forward for 150 mm
      Open the claw and go back to the center of the Field
      spin ClawMotor to position 0 degrees
      drive reverse for 150 mm
      turn left for 90 degrees
    else
      If the block is not red then the robot will drive back to the center
      drive reverse for 150 mm
      turn right for 90 degrees
```